

INSTALLATION GUIDE

GUIDE D'INSTALLATION /GUÍA DE INSTALACIÓN /INSTALLATION ANLEITUNG
GUIDA DELL'INSTALLAZIONE /GUIA DE INSTALAÇÃO /SPOSÓB INSTALACJI
INSTALLATIE GIDS /INSTALAČNÍ PRŮVODCE /ΟΔΗΓΟΣ ΕΓΚΑΤΑΣΤΑΣΗΣ


DRAGONFLY KIT

MULTIMEDIA WIRELESS
KEYBOARD & MOUSE SET





multimedia keys



ENGLISH

FN+F1 Multimedia	FN+F7 Play/Pause
FN+F2 Volume down	FN+F8 Stop
FN+F3 Volume up	FN+F9 Internet
FN+F4 Mute	FN+F10 Mail
FN+F5 Previous	FN+F11 My PC
FN+F6 Next	FN+F12 Favourites

FRANÇAIS

FN+F1 Multimédia	FN+F7 Lecture/Pause
FN+F2 Baisser le volume	FN+F8 Stop
FN+F3 Monter le volume	FN+F9 Internet
FN+F4 Silence	FN+F10 Courrier électronique
FN+F5 Précédente	FN+F11 Mon PC
FN+F6 Suivante	FN+F12 Favoris

ESPAÑOL

FN+F1 Multimedia	FN+F7 Reproducir/pausa
FN+F2 Bajar volumen	FN+F8 Stop
FN+F3 Subir volumen	FN+F9 Internet
FN+F4 Silencio	FN+F10 Correo
FN+F5 Anterior	FN+F11 Mi PC
FN+F6 Siguiente	FN+F12 Favoritos

DEUTSCH

FN+F1 Medienverbund	FN+F7 Wiedergabe / Pause
FN+F2 Lautstärke verringern	FN+F8 Stop
FN+F3 Lautstärke erhöhen	FN+F9 Internet
FN+F4 Stumm	FN+F10 Elektronische Post
FN+F5 Voriger	FN+F11 Mein PC
FN+F6 Nächster	FN+F12 Favorite

ITALIANO

FN+F1 Multimedia	FN+F7 Play / Pausa
FN+F2 Volume giù	FN+F8 Stop
FN+F3 Volume alto	FN+F9 Internet
FN+F4 Mute	FN+F10 E-mail
FN+F5 Precedente	FN+F11 Il mio PC
FN+F6 Successiva	FN+F12 Preferiti

PORTUGUÊS

FN+F1 Multimídia	FN+F7 Reproduzir/Pausa
FN+F2 Volume baixo	FN+F8 Stop
FN+F3 Volume alto	FN+F9 Internet
FN+F4 Mudo	FN+F10 Correio eletrónico
FN+F5 Anterior	FN+F11 O meu PC
FN+F6 Seguinte	FN+F12 Favoritos

POLSKI

FN+F1 Multimedia[ny]	FN+F7 Odtwarzaj/Zatrzymaj
FN+F2 Zmniejszanie głośności	FN+F8 Stop
FN+F3 Zwiększenie głośności	FN+F9 Internet
FN+F4 Niemy	FN+F10 Pocztą
FN+F5 Poprzednia	FN+F11 Mój PC
FN+F6 Następna	FN+F12 Ulubione

ΕΛΛΗΝΙΚΑ

FN+F1 Πολυμέσα	FN+F7 Αναπαύραση / παύση
FN+F2 Μείωση έντασης	FN+F8 Stop
FN+F3 Αύξηση έντασης	FN+F9 Internet
FN+F4 άφωνος	FN+F10 Ταχυδρόμιο
FN+F5 Προηγούμενο	FN+F11 PC μου
FN+F6 Επόμενο	FN+F12 Αγαπημένα ηλεκτρονικά